Master DFB16

schemat

www.klimasklep.pl
kontakt: https://klimasklep.pl/kontakt

MASTER®
CLIMATE SOLUTIONS

DSH0965

FAN

DFB 16



FUNCTIONING PRINCIPLES



The air flow is forced through the axial fan. Air is sucked in the rear and outlet takes place in front of the machine.

TECHNICAL DATA

Power supply	V	**110-240**	Noisy level	dBa	**51**
Power supply (adapter)	Vdc	**18**	Air displacement	m³/h	**1200**
Frequency	Hz	**50-60**	rpm	n°	**1300**
Rated current	A	**1,3**	IP protection	IP	**1X**
Power	W	**20**			
Net weight	kg	**6,3**			
Gross weight	kg	**8**			


PACKAGING

Dimensions packing	mm	**570 x 320 x 505**
Dimensions utilization	mm	**550 x 270 x 520**
Pieces for Euro-pallet	n°	**20**
Pieces per truck 80m^3	n°	**660**

ACCESSORIES

Battery 6 Ah

WIRING DIAGRAM





www.klimasklep.pl

kontakt: https://klimasklep.pl/kontakt